

4 channels remote control duplicator for these remotes:

**FIXED CODE AS BELLOWS:**

AETERNA TX433-1, TX433-2, TX433-3, TX433-4, 433 MHz 1K mini, 433 MHz 2K mini  
ADYX ALIZE EM2C, EM4C  
ALLMATIC AEMX1, AEMX2, AEMX4, EUROPE ARMY1, EUROPE ARMY2, EUROPE ARMY4,  
MX1, MX2, MX4  
ALLTRONIC S429-1, S429-2, S429-4, S429-mini 433 MHz red, S425  
ANSONIC SA434-1E, SA434-2E, SA434-3E, SA434-4E, SA434-5E, SA434-1MINI, SA434-2MINI,  
SA434-2Midi  
APERTO CPS1, CPS2, CPS4  
AVIDSEN 100601, 100951, 100955, 610955, 104505, 100550, 100400  
BELFOX DHS433-1, DHS433-2, DHS433-4, DHS 7733  
BENINCA LOT1W, LOT1WM, LOT2W, LOT4W, LOT2WMS, T2WK, T4WK, LOTX1W,  
LOTX2W, LOTX4W, TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK  
BESIDE BEZAP, HIT  
BFT TE01, TE02, TE04  
BANDY C4 blue, C4 orange, D2, D4  
CAME T432, T434, TOP432A, TOP434A, TOP432S, TOP432EV, TOP434EV, TOP432EE,  
TOP434EE, TOP432NA, TOP434NA, TOP432M, TOP434M, TOP432SA, TOP434MA, TWIN2,  
TWIN4  
CARDIN S476 TX2, S476 TX4  
CASALI Genius 433 2, Genius 433 3, JA400, JA401, JA400 TM433, JA401 TM433,  
CASIT ERTS92B, ERTS92T, ERTS20DB, ERTS20DQ, ERTS476D, ERTS476Q, TXS1, TXS2, TXS3,  
TXS4, ERTS97B, ERTS97TCELINSA S10 1, S10 2, S10 3, SAW1, SAW2, SAW3  
Centurion Classic 1 TX1CV2403, Classic 2 TX2CV2403, Classic 3 TX3CV2403  
Clemsa MV12  
CPS TCP3, Jolly 4, CPS1, EM1CV, CPS2, EM2CV, CPS4, EM4CV  
DASPI Happy2, ZERO 2, Pops2A, POPS433  
DEA 433 1 237, 433 2 238, 433 4 239, MIO TD2, MIO TD4, Punto 2 268, Punto 4 269, Genie 263,  
wood 263L, Gold R2, Gold R4  
DELMA Mizard 433 1, Mizard 433 2, KING 433MHz 2CH, KING 433MHz 4CH  
DICKERT MAHS433 01, MAHS433 04, S10-433A1L00, S10-433A4L00, S20-433A1L00,  
S20-433A4L00, S5-433-A2L00, S5U-433-A2L00  
DITEC BIXLS2  
DOITRAND MPSTF2E GREEN, MPSTF4E GREEN, MPSTF2E GREY, TS2DE, TS4DE  
DOORMATIC SAW 1, SAW 2, SAW 3  
DUCATI / ALLDUCKS TSAW1, TSAW2, TSAW3, 124, TSAW2 N, TSAW4 N, TE2  
DUCATI / ALLDUCKS / RONDY TPR10-A, TPR20-A  
ELBE 501, 502, 504, 502a, 504a  
ELBER/RONDY TSAW1, TSAW2, TSAW3  
ELCA IRIS E700, IRIS E700R, ASTER2, ASTER4, ASTER E1001, ASTER E1002, VIRGO,  
ASTER2 E800  
ELKA SKX1LC, SKX2LC, SKX3LC, SKX4LC, SKWD1, SKWD2, SKWD4, SKJmini, SKX1,  
SKX2, SKX3, SKX4, SKX1MD, SKX2MD, SKX3MD, SKX4MD  
FAAC TM 433DS-1, TM 433DS-2, TM 433DS-3  
FADINI ASTRO 433-2, ASTRO 433-4, ASTRO 433-2TR SMALL  
GIBIDI OPEN-TMB 433  
GULLIVER MDW-2E  
MA-SYSTEM TX1, TX2, TX3  
Micromark MM23164  
NICE FLO1, FLO2, FLO4

PRASTEL MPSTF2E  
PROEM ER2C4 ACD  
PROGET EMY 433 2C, EMY 433 4C, ETY N2, ETY N4  
Proteco MICRO TX1/2/3 433Mhz  
PUJOL TRINARIO1  
RIB WECLA, MOON, SUN  
SEAV BE HAPPY S1, BE HAPPY S2, TXS1, TXS2, TXS3, TXS4  
STARTEC TX-Q2  
TAU 250BUG2, 250BUG4, 250-K-slim, 250 SLIM, 250TXD2, 250TXD4, 250 T4  
TELCOMA EDGE 2, EDGE 4, Tango Slim 2, Tango Slim 4, Tango 2, Tango 4, Tango 2SW, Tango  
4SW, Tango WIN3, Tango Blue 2, Tango Blue 4  
V2 TRR2-43, TRR4-43  
ZULLAN 250DX2D

PT2262 PT2240 PT2264 PT2260 PT2242 AX5326-4 AX5326-3 SC2262 SC2260 HS2262 LX2262  
EV1527 P527 HT12D HT12F HT12E HT6P20B HT6P20D HT6P237A HT6P247A HT6P427A  
HT6P437A HT600 HT680 HT640 HT6010 HT6012 HT6014 SC5262 SM5028RF SM5028S  
SMC5326P-3 HCS101 HCS200及HCS201 (部分代码) HCS300及HCS301 (部分代码)

**ROLLING CODE:**

**BFT MITTO 2, BFT MITTO 4, DOORHAN 433MHZ, BENINICA TOGO, FADINI  
JUBI**